



#3: align the rain gauge body and screw it back. Remember to align the funnel with the arrow markers on funnel and rain gauge body.

#4: for areas with heavy dust, please tape to seal the rain gauge body water outlet holes ( only leave a few holes under the rain bucket) to stop dust from entering the body.